



Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli



XX = AA, AD,


- 1 - B 961564 XX
- 2 - B 964696 NU
- 3 - B 964697 XX
- 4 - B 964698 NU
- 5 - B 961478 NU
- B961477NU-BC650..
- 6 - B 961202 XX
- 6a - B 960962 XX
- 7 - B 960497 NU
- 8 - B 960839 NU
- 9 - B 960712 XX
- 10 - B 964702 NU
- 11 - B 960535 NU
- 12 - A 960196 NU
- 13 - B 961947 NU




Ideal Standard

ALPHA

03.2025 / B665960



B C660 ..



B C650 ..



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
www.idealstandard.com



