



ŚCIANKA S1 / SIDEWALL S1

Model	A2	X2	Y2
S1 70	700	692-702	673-683
S1 75	750	742-752	723-733
S1 80	800	792-802	773-783
S1 90	900	892-902	873-883
S1 100	1000	992-1002	973-983
S1 110	1100	1092-1102	1073-1083
S1 120	1200	1192-1202	1173-1183

KDJI DRZWI / DOORS

Model	A1	X1	Y1	B	D	H
KDJI Front 80	800	795-801	773-779	720	708	2000
KDJI Front 90	900	895-901	873-879	820	808	2000
KDJI Front 100	1000	995-1001	973-979	920	908	2000

