



Model	A1	A2	X1	X2	Y1	Y2	B1	B2	C1	C2	D	H
KDD 75Lx90R	750	900	736-746	886-896	717-727	867-877	520	620	207-217	257-267	805	1850
KDD 80Lx80R	800	800	786-796	786-796	767-777	767-777	520	520	257-267	257-267	740	1850
KDD 80Lx90R	800	900	786-796	886-896	767-777	867-877	520	620	257-267	257-267	805	1850
KDD 80Lx100R	800	1000	786-796	986-996	767-777	967-977	520	620	257-267	357-367	805	1850
KDD 90Lx75R	900	750	886-896	736-746	867-877	717-727	620	520	257-267	207-217	805	1850
KDD 90Lx80R	900	800	886-896	786-796	867-877	767-777	620	520	257-267	257-267	805	1850
KDD 90Lx90R	900	900	886-896	886-896	867-877	867-877	620	620	257-267	257-267	880	1850
KDD 90Lx100R	900	1000	886-896	986-996	867-877	967-977	620	620	257-267	357-367	880	1850
KDD 100Lx80R	1000	800	986-996	786-796	967-977	767-777	620	520	357-367	257-267	805	1850
KDD 100Lx90R	1000	900	986-996	886-896	967-977	867-877	620	620	357-367	257-267	880	1850
KDD 100Lx100R	1000	1000	986-996	986-996	967-977	967-977	620	620	357-367	357-367	880	1850